


I N F O



I N S T R U C T I O N B O O K L E T

FRIDGE FREEZER


ER 2940B ER 2941B ER 2340B ER 2341B

 **Electrolux**

CONTENTS

IMPORTANT INFORMATION	2
YOUR APPLIANCE	
Important Points To Remember	3
HOW TO INSTALL YOUR APPLIANCE	
Positioning	4
Reversible Hinging	4
Foot Adjustment	5
Electrical Requirements	5
Before Using Your Appliance	6
Final Check	6
Starting	6
Normal Sounds	6
HOW TO USE THE CONTROLS	
Temperature Control	6
Warning Lights	7
Fast Freeze Facility	7
YOUR FRIDGE COMPARTMENT	
Temperatures	7
Fresh Food Compartment	7
Door Storage	8
Helpful Hints When Buying Food	8
Preparing Foods For Storage	8
Fresh Food Storage Guide	9
Automatic Defrost	9
YOUR FREEZER COMPARTMENT	
Temperatures	10
Helpful Hints When Buying Food	10
Frozen Food Storage	10
Freezer Fresh Food	10
General Food Preparation	11
Ice Making	11
Prepared Foods	11
Cool Food Quickly	11
Open Freezing	11
Packaging	11
Labelling	11
Thawing Foods	12
Defrosting Your Freezer	12
FOOD FREEZING GUIDE	13-14
CARING FOR YOUR FRIDGE/FREEZER	
Replacing The Light Bulb	15
Cleaning And Care	15
If Going On Holiday	15
SOMETHING NOT WORKING	
Service Check	15
Rating Plate	16
HELP US TO HELP YOU	
Service	16
Customer Care	16
ELECTROLUX SERVICE CENTRES	17
GUARANTEE	

IMPORTANT USER INFORMATION



PLEASE READ THIS
INSTRUCTION BOOK
BEFORE USING THE
APPLIANCE

IT IS MOST IMPORTANT THAT THIS INSTRUCTION BOOK SHOULD BE RETAINED WITH THE APPLIANCE FOR FUTURE REFERENCE. SHOULD THE APPLIANCE BE SOLD OR TRANSFERRED TO ANOTHER OWNER, OR SHOULD YOU MOVE HOUSE AND LEAVE THE APPLIANCE, ALWAYS ENSURE THAT THE BOOK IS SUPPLIED WITH

THE APPLIANCE IN ORDER THAT THE NEW OWNER CAN BE ACQUAINTED WITH THE FUNCTIONING OF THE APPLIANCE AND THE RELEVANT WARNINGS.

THESE WARNINGS ARE PROVIDED IN THE INTEREST OF SAFETY, YOU MUST READ THEM CAREFULLY BEFORE INSTALLING OR USING THE APPLIANCE.


- ▲ Any electrical work required to install this appliance should be carried out by a qualified electrician or competent person. Under no circumstances should you attempt to repair the appliance yourself. Repairs carried out by inexperienced persons may cause injury or more serious malfunctioning. This product should be serviced by an authorised service engineer and only genuine Electrolux Spare Parts should be used.

It is dangerous to alter the specifications or modify this product in any way. This product is designed for domestic use only and should be operated by adults. Children should not be allowed to tamper with the controls or play with the product.

- ▲ The appliance should be left for 2 hours after installation before it is turned on to allow the refrigerant to settle. Care must be taken to ensure that the appliance does not stand on the electrical supply cable.
- ▲ Many parts at the back of this appliance heat up and should not be exposed. When positioning this appliance ensure there is adequate ventilation. Failure to do this will result in component failure and possible food loss.
This appliance is heavy. Care should be taken when moving it.
- ▲ Electrolux domestic fridge freezers are designed to be used specifically for the storage of edible food stuffs only. Food manufacturers storage recommendations should be strictly adhered to. Refer to relevant instructions.
- ▲ Care must always be taken when handling food in the home. Always follow the basic rules of food hygiene to prevent bacterial and microbial growth and cross contamination when defrosting, preparing, cooking, cooling, reheating and freezing foods.
- ▲ Before defrosting, cleaning or maintenance work is carried out, be sure to switch off the appliance and unplug it.
- ▲ Your fridge freezer is designed for operation in a domestic household. If it is used in a non-domestic situation the guarantee may be invalidated.
- ▲ The evaporator plate and aluminium lining or refrigerated freezer shelves in this appliance contain channels through which the refrigerant passes. If these are punctured this would cause substantial damage to the appliance and result in food loss.
DO NOT USE SHARP INSTRUMENTS to scrape off frost or ice. Under no circumstances should ice be forced off the lining or shelves. Solid ice should be allowed to thaw when defrosting the appliance. See defrost instructions.
- ▲ Do not place carbonated fizzy drinks in the freezer as it created pressure on the container which may cause it to explode resulting in damage to the appliance.
- ▲ Ice lollies can cause frost burns if consumed straight from the freezer.
- ▲ Frozen food must not be refrozen once it has thawed out.
- ▲ Manufacturers' food storage recommendations should be strictly adhered to. Refer to relevant instructions.


YOUR APPLIANCE

Model ER2940B/ER2941B



1. Warning Lights
2. Control Housing
3. Interior Light
4. Drink Cooler
5. Adjustable Shelf
6. Meat Tray
7. Salad Drawer
8. Adjustable Door Shelf

Model ER2340B/ER2341B



9. Cooling Plate
10. Half Width Door Shelf
11. Defrost Drain
12. Door Shelf with Bottle Grip
13. Ice Store
14. Freezing/Storage Shelf
15. Storage Baskets
16. Storage Drawer
17. Defrost Flip Spout
18. Lever Adjusters (in all 4 feet)

For best results, it is important that you read all the contents of this handbook before you use your fridge freezer.

IMPORTANT POINTS TO REMEMBER

DO ...

Adjust the level of your appliance before loading it with food.

Cover or wrap liquids and foods, particularly those with strong odours.

Put vegetables and salads in the salad drawers, in plastic bags.

Leave the doors ajar when the appliance is not in use.

Rotate stocks of frozen foods. Date markings will help with this.

DON'T...

Leave the drink cooler with residue in it which might harden or go stale. Always rinse out and dry the container as soon as it becomes empty.

Leave the door open for long periods as this will make the fridge more costly to run.

Cover the shelves with any protective materials which may obstruct air circulation through them.

Use a sharp instrument to hasten defrosting or to remove ice trays.


Put hot food in the appliance.

HOW TO INSTALL YOUR APPLIANCE

POSITIONING

This appliance is designed to operate in ambient temperatures between 10°C (50°F) and 32°C (90°F). It should be located in a dry atmosphere, out of direct sunlight and away from extreme temperature e.g. not next to a cooker or other sources of direct heat, or in a very cold room e.g. an outhouse, where the temperatures may fall below 10°C (50°F). If these ambient temperatures are exceeded the food storage temperatures given on page 9, 13 & 14 will not be maintained.

Fig. 2




The appliance should be gently pushed into place until the top panel rear ventilation grill touches against the wall. (See Fig. 2). When in position a 50mm (2") clear space above the appliance should be maintained. If a clear space of 50mm (2") above the appliance is not available, clearances of 25mm (1") should be maintained on both sides.

REVERSIBLE HINGING

If your fridge/freezer is already in use, disconnect it from the electricity supply and remove shelves and other loose items, including food. Place frozen food in boxes wrapped in blankets or other suitable insulating material and put in a cool place.

Open the upper door. While firmly holding the door with one hand, remove the screw (1) (fig. 3) which secures the hinge plate (2) and slide the bottom of the door to the right; be ready to catch the hinge plate (2) as it is released.

Fig. 3



Carefully disengage the door from the upper hinge pin (4) (fig. 4).

Unscrew the upper hinge pin (4) and transfer it to the opposite side.

Lift off the plastic cover (5) (fig. 5).

Open the lower door and, holding it securely, remove the hinge pin (7) (fig. 5) which supports the top of the

door, by lifting it upwards. With the door closed, transfer the pin (7) to the corresponding position on the opposite side. Fit the plastic cover (5) to the hinge support at the end opposite to its original position.

Fig. 4






Fig. 5



Refit the upper door by engaging the top of the door with the upper hinge pin (4). Place the hinge plate (2) in its new position at the bottom of the door. Engage the ribs on the underside of the hinge plate with those on the corresponding section of the support (6) (fig. 5).


Fit and tighten the screw (1).

Fig. 6



Gently lay the appliance on its back with the top held away from the floor by at least 30cm (12") (use a stool or something similar) (See fig. 6).

Fig. 7



Remove level adjuster (8) (fig. 7) from the small foot assembly. The small foot (9) can now be removed by

removing screw (10). In order to remove the large foot/hinge assembly (11) screws (12, 13, 16) should be removed making sure that the spacer (14) is retained with the assembly.

Pull out the lower hinge pin (15) which may have come away with the hinge blade or remained in the door. Push the pin (rounded end) into the bush at the bottom of the door on the side opposite to its original position.

Taking care not to press down on the door. The large foot/hinge assembly should be transferred over to the opposite side of the cabinet and screws (12, 13, & 16) moved over to their new positions in the hinge foot (see fig. 7). It is important that the spacer (14) is retained with screw (12) in the channel between the base of the product and the foot/hinge assembly when screwing the foot/hinge assembly into its new position.

Refit the small foot, its screw entering the hole furthest from the front on the flat portion of the base.

Replace the level adjuster (8).


Stand the appliance upright.

Side adjustment to the upper door can be made by loosening the screw (1) (see fig. 3) and moving the bottom of the door sideways a little (with the hinge plate) to the left or to the right. Be sure to support the door firmly while doing this and re-tighten the screw before testing. remember finally to carefully level the fridge/freezer by means of the level adjusters (8) in the feet.

FOOT ADJUSTMENT

Your appliance will be heavy when loaded with food and must therefore be stood on a strong firm floor. It should also be level. Adjust the level by screwing out the appropriate level adjusters in the front feet using your fingers or a suitable spanner (see fig. 8). Level adjusters are also available in the rear feet in the event of excessive floor unevenness. Make sure the appliance is upright and all adjusters are in firm contact with the floor so that the cabinet doesn't rock in any direction.

Fig. 8



ELECTRICAL REQUIREMENTS

Before switching on, make sure that the voltage of your electricity supply is the same as that indicated on the rating plate. This is located inside the cabinet behind the salad drawer.

WARNING THIS APPLIANCE MUST BE EARTHED.

If this appliance is fitted with a non rewirable plug for which your socket is unsuitable the plug should be cut off and an appropriate plug fitted. The removed plug should be disposed of as an insertion of the plug into a 13A socket is likely to cause an electrical hazard. If it is necessary to change the fuse in a non rewirable plug the fuse cover must be replaced. If the fuse cover is lost or damaged the plug must not be used until a replacement is obtained.


Replacement fuse covers are available from your nearest customer service centre. It is important that the colour of the replacement fuse cover corresponds with the colour insert or as embossed in words on the base of the plug.

IMPORTANT – The wires in the mains lead are coloured in accordance with the following code:

GREEN & YELLOW	: EARTH
BLUE	: NEUTRAL
BROWN	: LIVE

As the colours of the wires in the mains lead of this appliance may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:

The wire which is coloured green and yellow must be connected to the terminal which is marked with the letter 'E' or by the Earth Symbol \equiv or coloured Green or Green-Yellow. The wire which is coloured Blue must be connected to the terminal which is marked with the letter 'N' or coloured Black. The wire which is coloured Brown must be connected to the terminal which is marked 'L' or coloured Red.



The appliance must be protected by a 13A ASTA approved (BS1362) fuse, if a 13A (BS1363) plug or a non rewirable plug is used, or if any other type of plug is used a 15A fuse either in the plug or adaptor or at the Distribution Board.

If at any time a replacement lead is required, the cross sectional area of its conductors must not be less than 0.75mm².

If it becomes necessary to replace the supply cord, the cable clamp should be tightened so as to retain the new cord.

We recommend that the installation be checked by a qualified electrician who can ensure that the appliance is operating satisfactorily and that it has not been damaged in transit.

BEFORE USING YOUR APPLIANCE

Wash the interior of the appliance using a solution of 5ml (1 teaspoonful) of bicarbonate of soda to each 500ml (1 pint) of warm water and dry very thoroughly with a clean dry cloth. Detergents or soap should not be used as they leave a trace of odour. Abrasive cleaning powders must not be used on any interior part as they may effect the finish.

Care should be taken when opening and closing the door not to trap your fingers between the top of the door and front moulding. Always use the door handle.

FINAL CHECK

Before starting to use your appliance, please check it has been thoroughly dried inside and air can circulate freely.

The feet have been adjusted and all four feet are firmly in contact with the floor.

STARTING

Plug into the mains and switch on. Check that the mains warning light comes on and the control dial is correctly set. (See "How to set the Controls"). You will hear the compressor start up.

NORMAL SOUNDS

It is quite normal for refrigerators and freezer to make a certain amount of noise. The noise level will vary according to where the cabinet is positioned.

Noise and vibration can arise if the cabinet is unsteady or is close up to some other fitment such as a sink unit or dishwasher.

Refrigerating System. A faint gurgling or bubbling sound can be heard when refrigerant is pumped through the coils of tubing at the rear, the cooling plate or the freezer shelves.

Compressor. When the refrigerant is pumped round, a whirring or pulsating noise may be heard from the compressor.

Thermostat. The compressor is started and stopped by the thermostat. A click can be heard when the thermostat cuts in and out.

HOW TO USE THE CONTROLS

TEMPERATURE CONTROL

The operating controls are situated under the flap at the front of the top panel.

To start the cooling system, plug into the wall socket and switch the mains on.

The temperature in the fridge and freezer compartments will be affected by location, room temperature and frequency of door opening s and adjustment of the thermostat setting may be needed to allow for this. When operating the outside front edges of the freezer may feel warm to the touch. This is quite normal.


MODELS ER2940B, ER2941B

The freezer compartment is fitted with a pre-set thermostat (mounted at the rear of the top panel) and will store food at -18°C (10°F) under normal operating conditions. (No adjustment is required).

To operate the fridge compartment turn the thermostat (mounted under the flap on the top panel) to the position indicated in fig. 9.

If a lower temperature is needed (e.g. during hot weather), turn the thermostat knob clockwise towards max. or for less cooling anticlockwise towards min.


If colder settings are selected for extra chilling effect do not forget to turn the control dial back to the correct setting afterwards. We advise you to run your fridge freezer until the red warning light goes out before storing frozen food.



MODEL ER2340B, ER2341B

There is a single thermostat control which when set to the recommended position (see fig 10) provides suitable temperatures in both freezer and refrigerator compartments under most conditions of use.

If a lower temperature is needed (e.g. during hot weather), turn the thermostat knob clockwise towards max. or for less cooling anticlockwise towards min.



WARNING LIGHTS

The warning lights are situated in the right hand corner of the top panel.

Green Indicator Light – When the appliance is switched on at the mains the green indicator light will glow and continue to glow until the appliance is switched off at the mains.

Red Indicator Light (Model ER2940B, ER2941B only)
A few hours after starting up this will go out to show that the correct temperature has been reached for the setting chosen and will stay out to indicate that everything is in order.

If colder settings are selected for extra chilling effect do not forget to turn the control dial back to the correct setting afterwards. We advise you to run your fridge freezer until the red warning light goes out before storing frozen food.

It will come on if the freezer temperature rises unduly for instance, after opening the freezer door or placing food inside the cabinet, but the light should go out again when the temperature returns to normal.

Amber Indicator Light (Fast Freeze) (Model ER2940B, ER2941B only)
With the fast freeze switch on the Amber Indicator light will come on and stay on as a reminder.

FAST FREEZE FACILITY

(Model ER2940B, ER2941B only)
The fast freeze switch overrides the thermostat and should be used when freezing fresh foods.

YOUR FRIDGE COMPARTMENT


TEMPERATURES

The function of the fridge compartment is to reduce the development of organisms which cause decay and bacterial activity, and thus increase the storage life of food.


The fresh food compartment has been designed to operate between 0°C (32°F) and 5°C (41°F) and is in accordance with British and European Standards.

FRESH FOOD COMPARTMENT

The fridge compartment is fitted with shelves which are adjustable for the storage of different sized articles and may also be tilted for the storage of bottles of wine etc. (see fig. 11).



If your fridge freezer is positioned near to a wall thereby allowing the door to open through only 90° then each shelf when tilted can be removed as follows (see fig. 12).



The shelves are designed to allow maximum air circulation and therefore when placing foods on the shelves make sure a small space is left between the packages.

The warmest area in the fridge is to the top of the compartment and the coolest is at the bottom of the compartment and this is where the most perishable foods should be kept.

Vegetables and salad foods can be stored in the salad drawer. To ensure they are maintained in a crisp condition it may be necessary to wrap some foods in polythene bags e.g. lettuce, watercress or herbs.


DOOR STORAGE

Storing items in the door liner can eliminate searching in the main compartment. The lower door shelf should be used for the storage of heavier bottles whilst remaining shelves will accommodate fat, butter, small cartons and jars etc.

Adjustment of the door shelves can be made to accommodate varying heights of bottles and other containers (see fig. 13).

Enclosed storage compartments may be used to store dairy products and fats.

Fig. 13



HELPFUL HINTS WHEN BUYING FOOD

Always ensure that food your purchase is of good quality and in prime condition.

Shop at a reliable source and buy the "freshest" looking packing – avoid shop-worn labels or produce covered in dust.

Avoid buying chilled food if you cannot store it straight away. The use of an insulated container is advisable.

Buy and consume foods prior to the "Sell By" or "Best Before" dates.

When you arrive home place perishable foods in the refrigerator immediately.

Always follow the storage instruction recommended by the manufacturer on the packet.

PREPARING FOODS FOR STORAGE

Wash and dry soiled vegetables and fruit before storage. All vegetables and fruit should be washed before eating.

Foods should be covered before being placed in the refrigerator. Foil, plastic film, polythene and plastic food containers are suitable.

Covering foods not only prevents transfer of flavours and foods from drying out, but also prevents any possible cross contaminations with bacteria from raw to cooked foods. The position for storage of food in a refrigerator should be carefully selected so that cross contamination will not occur.

Different types of food such as raw meat, fish, dairy products and cooked food should be kept separately to avoid contamination from one another. Cooked foods should always be placed above raw meats.

Put fresh meat and defrosting foods on a plate, covered at the bottom of the fridge – if it drips onto other foods it can pass on food poisoning bacteria. Do not let meat drip into fresh vegetables and salads in the salad drawer.

With ready packed and pre-packed foods always check the label to see if the manufacturer has given any storage advice and follow accordingly. Many foods now have preservatives and antitoxins removed and this will reduce the shelf life of certain foods.

Hot food should not be put straight into the refrigerator because it can cause intensive work to the compressor and thus increase the energy consumption, and therefore it is important to cool cooked food quickly before putting it into the refrigerator.

Food should be cooled quickly to prevent bacterial growth and this may be done by transferring hot foods into a cold container and standing it in a sink filled with iced water. Ensure that the food is covered and stir at regular intervals to reduce the temperature quickly.

NEVER PUT HOT FOODS DIRECTLY INTO THE FRIDGE/FREEZER.

FRESH FOOD STORAGE GUIDE

The recommended storage times of food are as follows:

Shelf Position	Storage Time
Top Shelves	
Fats	10 days
Hard Cheese	7-14 days
Cooked Meats, Poultry	2 days
Bacon	7 days

Middle Shelves	
Milk and Cream	2-3 days
Soft cheese	2-3 days
Eggs	2 weeks
Desserts with cream/ custard	2 days

Shelf Position	Storage Time
Middle Shelves	
Pastry Products	3-4 days
Cooked Meat Pies/ Sausage Rolls	2 days
Cooked Fruit	up to 4 days

Bottom Shelves	
Stock and Gravies	2 days
Fresh Fish	eat same day
Fresh Meats	3 days
Fresh Poultry	2 days
Sausages	up to 3 days
Minced Meat, Burgers	1 day


Salad Drawer	
Green Vegetables	3-5 days
Salad Vegetables	3-5 days
Fresh Fruit	5 days

DO NOT KEEP BANANAS IN THE FRIDGE/FREEZER

AUTOMATIC DEFROST

The defrosting of the fridge compartment occurs automatically. There is a drain outlet situated at the back of the compartment, as indicated by a label on the inside wall. This drain outlet should be cleaned at regular intervals.

IT IS IMPORTANT THAT THE DRAIN OUTLET IS KEPT CLEAR AT ALL TIMES, IF BLOCKED CAREFULLY CLEAR IT USING A PIECE OF FLEXIBLE CURTAIN WIRE INSERTED INTO THE DRAIN OUTLET TO REMOVE BLOCKAGE.



YOUR FREEZER COMPARTMENT

TEMPERATURES

The ❄️ symbol means that your freezer will store frozen food at -18°C (-0°F) for long term storage and will also freeze fresh food.

It will store food at a temperature that is too cold for bacterial and enzyme activity which causes decay, thus increasing the storage life. If frozen correctly, food will retain texture, colour, taste and nutritional content.

Most fresh foods freeze well, however some freeze more successfully than others. Foods with a low proportion of water such as bread, cakes, pastry, meat, fish and poultry freeze exceptionally well. Similarly, game, dairy produce, fruits and vegetables all keep well in the freezer.

Foods with a high water content such as lettuce or marrow do not freeze well as the freezing process breaks down their cellular structure. Other foods which do not freeze well are mayonnaise because it separates, bananas because they turn black and whole eggs in their shells because they crack.

HELPFUL HINTS WHEN BUYING FOOD

Always ensure that the fresh food that you purchase is of a good quality and in prime condition.

Shop at a reliable source and buy the "freshest" looking packages – avoid shopworn labels or produce covered in dust.

Avoid buying frozen food if you cannot store it straight away. The use of an insulated container is advisable. When you arrive home place frozen foods in the freezer immediately.

FROZEN FOOD STORAGE

Your freezer has the following capabilities:

MODEL No.	NETT STORAGE VOLUME	WEIGHT OF STORED FOOD
ER2940B ER2941B	129l (4.6cuft)	41.7kg (92lb)
ER2340B ER2341B	101l (3.6cuft)	32.3kg (71lb)

This is a standard measurement and the actual capacity depends upon the density and sizes of the food. The above figures are based on an average density of 0.32 kg per litre (20lb per cuft.)

Pre-packed commercially frozen food should be stored in accordance with the manufacturers' instructions for a 3 star frozen food compartment and should be put in the freezer as soon as possible after purchase. Your freezer provides for long term storage which generally means up to 3 months but the length of storage time can vary and it is important to follow the recommended times

shown on packets of commercially frozen food.

Storage time for home prepared fresh foods are given on page 14.

Any opened packets of frozen foods should be rewrapped in air tight materials to prevent surface evaporation which causes drying or "freezer burn".

Important

If the temperature rises in frozen foods because of:

- non compliance with manufacturers instructions
- electric power failure.

then recommended storage life may be reduced and storage times may not apply.

Frozen food which is allowed to thaw accidentally should either be used immediately or thrown away.

Alternatively if the food is uncooked and it has not been completely defrosted it can be cooked then refrozen.

FREEZING FRESH FOOD

During the freezing process the temperature of fresh food should be reduced quickly so that ice crystals are kept as small as possible to prevent damaging the structure of food. If freezing takes place slowly large ice crystals form and these will affect the quality of food once it has defrosted. In any 24 hours you can freeze as much as:-

MODEL No.	WEIGHT OF FROZEN FOOD
ER2940B ER2941B	9kg (20lb)
ER2340B ER2341B	10kg (22lb)

The packets of food to be frozen should be placed apart to allow cold air to circulate between them. They should not touch existing packets.

During the freezing process ensure that the door remains closed.

For safety reasons, the freezer baskets (when fitted) are fitted with stops but are readily removed by pulling them forward to the stop, then lifting the front and pulling them the way out. Re-fit by reversing this procedure.

Note:

Aim to check dates on packets and rotate food regularly. Although storage longer than recommended is not harmful, flavours and textures begin to deteriorate.

GENERAL FOOD PREPARATION

Fruit & Vegetables: Fruit and vegetables should preferably be frozen immediately after picking or purchasing or kept in a refrigerator for no longer than twenty four hours.

For perfect results fruit should be just ripe, and if any show signs of being damaged it should be discarded. Most vegetables and some fruit need to be blanched before freezing to retard enzyme reaction. Timings for individual types are given in the tables on pages 13 – 14.

Blanching: Where necessary plunge vegetables into boiling water for the specified period, and time from the moment they return to boil. Drain and cool immediately in iced water before packaging and freezing.

Meat: Freeze joints in handy-sizes after trimming fat and removing bones if necessary. Game must be hung for the required period and cleaned before being hung.

Poultry: Gut, singe and wash birds thoroughly. Tie legs and wings to the body before placing in the freezer, or cut into joints for packing separately. Giblets should be packed separately.

Fish: All types of fish should be preferably frozen within 24 hours of being caught. Any superfluous scales should be removed along with the fins, then the fish gutted and washed clean in cold salted water before being frozen.

ICE MAKING

It may be necessary to build up a supply of ice cubes when entertaining or for a spell of hot weather when ice will be in demand.

First, make ice cubes by filling the ice tray with fresh drinking water to the top of each ice cube compartment and placing on the freezer shelf. When ice cubes have formed, hold the tray upside down and twist the tray along its length, allowing loosened cubes to fall into a plastic container or polythene bag. Store in the freezer and use when required.

PREPARED FOODS

These freeze well, but remember that seasonings may become stronger during frozen food storage. Salt shortens the storage time of frozen food so add a little more if necessary during preparation for eating. Semi-liquid foods have a tendency to thicken, so should be made up with a little more liquid than normal. Highly spiced and aromatic dishes should be wrapped thoroughly, so the flavour does not transfer to other frozen foods. Always cool prepared foods quickly and freeze immediately.

DO NOT PLACE HOT FOODS INTO THE FREEZER.

COOL FOODS QUICKLY

Hot food should not be put straight into the freezer because it can cause intensive work for the compressor and thus increase the energy consumption. Therefore it is important to cool cooked foods quickly before putting them into the freezer.

Food should also be cooled quickly to prevent bacterial growth and this may be done by transferring hot foods into a cold container and standing it into a sink filled with iced water. Ensure that food is covered and stir at regular intervals to reduce the temperature. Once cooled transfer food into a container suitable for freezing.

OPEN FREEZING

This method is commonly used to freeze fruits and vegetables. After preparation place the food in a single layer on foil covered baking sheets, trays or special fast freeze trays, ensuring that the items do not touch each other. Freeze the food uncovered until hard (usual 1-2 hours), after which it can be packed into polythene bags. This method produced free flow packs which means that portions, whatever size, can be taken out as required. Open freezing is also useful for delicate foods which could become damaged during packing, e.g. decorated cakes, flans and pastries.

PACKAGING

It is important to use the correct packaging to preserve the quality of frozen food. All foods should be wrapped in moisture proof materials and be completely covered. The most useful materials are heavy gauge polythene bags or sheeting, plastic containers with tight fitting lids, aluminium foil, aluminium foil containers and waxed cardboard containers.

Plastic film can be used as an inner wrapping for food which is then over wrapped with a polythene bag, or can be used to interleave small items such as chops, steaks, burgers etc., so that they can be removed individually. Use freezer quality film or double wrap food items with standard kitchen film.

Pad any sharp protruding bones on meat and poultry with foil or plastic film to prevent the bag being pierced during freezer storage. A range of closures are available including bag ties, heat sealers and self seal type polythene bags.

Boiling bags can be used to both pack food in for freezing and for reheating that same food in a pan of boiling water. They are especially useful for items such as new potatoes, sauces and single portions of cooked foods. As much air as possible must be extracted from the bag and an effective seal is essential.

Pack foods in even shapes to maximise space available in your freezer and facilitate removal when required later.

LABELLING

The most useful label is probably the self adhesive type as it can be used on every kind of surface. Information to be written on the label should include the type of food, approximate weight or likely number of servings, and any comments relevant to ultimate use. It may be necessary to keep a notebook handy to enable you to rotate stocks and keep reference on what type of foods are being used at one time.

THAWING FOODS

Most foods can be thawed in their original wrapping to maintain moisture and prevent any deterioration. Foods should be thawed in a cool place such as a refrigerator or if food is required quickly a microwave oven may be used, remembering to transfer foods from foil containers and remove wire ties from plastic bags. Always follow the instructions in the microwave oven's manual for thawing frozen food. It is essential that all foods particularly meat and poultry are completely defrosted before cooking.

Fruit: Keep container closed and allow to thaw at room temperature for about five hours.

Vegetables: It is not necessary to thaw before cooking – place in salted boiling water, cover and time cooking from moment of return to boil which only takes a few minutes. Some vegetables can also be put in the oven with a knob of butter and some may be deep fat fried.

Meat & Poultry: Thaw completely before cooking by preferably leaving to defrost slowly in a refrigerator. If required quickly, a microwave oven may be used or allow 2 to 4 hours per 1/2 kg. (1lb.) at room temperature. To check whether or not poultry is defrosted the legs should be able to move freely and there should be not ice crystals present.

Dairy Products: Allow eggs to thaw in closed containers and use immediately. Butter and cream depending on the quantity will thaw in one to two hours at room temperature. Do not freeze eggs in their shells as they will crack.

Baked Items: Bread takes about two hours to thaw or loaves may be heated in the oven. Cakes can be sliced in their frozen state to retain shape and speed the thawing process.

Prepared Foods: Heat gently in closed containers in the oven and season if necessary.

Commercial Packs: Follow the printed instructions given by the manufacturers.

DEFROSTING YOUR FREEZER


Complete defrosting will in the course of time become necessary. This should be carried out if the frost build up cannot be all scraped away or if it begins to interfere with the food storage. Choose a time when the stock of frozen food is low and proceed as follows:

Take out the frozen food. Switch the appliance off at the mains and leave the door open.

Ideally the foods should be put into another freezer or refrigerator. If this is not possible, wrap it in a compact block, first in several sheets, newspapers or thick towels, then in a thick rug or blanket. Keep it in a cool place.

Fold out the defrost flip spout, put a suitable container under it to collect the defrost water, and leave the door open (see fig. 14).

Fig. 14



Scrape away as much frost as possible. Thawing of the remainder can be accelerated by placing bowls of hot water on the shelves inside the cabinet. As the solid frost loosens, prise it away with a wooden or plastic scraper. When defrosting is complete empty container. Wipe over the cabinet and the door with bicarbonate of soda and water and dry thoroughly as described under "Cleaning and Care".

When the cabinet is completely dry and clean, close the door and switch on at the mains. Switch on the Fast Freeze switch and run for 30 minutes before reloading with frozen foods. Switch off the fast freeze after approximately 3 hours.

IMPORTANT NOTE

Provided our recommendations for the periodic removal of frost are followed, the defrosting should be complete within 2 hours. Provided the frozen food has been wrapped during defrosting as described above, it can be replaced in the freezer. If for any reason the defrosting process has taken longer than 2 hours the outside of the frozen foods may begin to soften.

Provided the foods have not completely thawed they will refreeze satisfactorily, although repeated rises in temperature may cause slight deterioration in quality.

FOOD FREEZING GUIDE


	Max. Storage Period	Method	Remarks
MEAT joints			
Beef	10-12 months	Remove additional fat Cut to handy size wrap thoroughly	Pad bone ends
Pork	6 months	Cut to handy size wrap thoroughly	ditto
Lamb	9 months	Cut to handy size wrap thoroughly	ditto
Steak	10-12 months	Open freeze or interleave with plastic film	ditto
Chops	See Pork or Lamb above	ditto	ditto
Veal Fillets	6-9 months	ditto	
Bacon, cured smoked	6 weeks 1 month	ditto	Pack in handy meal portions
Sausages	6 weeks	Wrap tightly	Pack in handy meal portions
Minced meat	2 months	Wrap tightly	Pack in handy meal portions
Offal and tripe	3 months	Clean thoroughly, remove tubes cores and fat, pack in small portions	Make sure it is really fresh
POULTRY			
Chicken	9-12 months	Clean in usual way, joint if necessary, wrap thoroughly	Wrap giblets separately, pad bone ends. Do not stuff till ready.
Turkey	9-12 months	Clean in usual way, joint if necessary	ditto
Duck, Goose	6 months	Clean in usual way, joint if necessary	ditto
Giblets	3months		Wrap separately from bird
Game	6 months	Hang before freezing	Cook immediately after thawing
FISH			
All types	3 months	Clean, descale, discard head and tail, wrap separately	Must be fresh
Trout	3 months	Clean, descale, discard head and tail, wrap separately	Must be fresh
Salmon	3 months	Clean, stuff with greaseproof paper for shape retention or cut into steaks, cutlets or fillets	Must be fresh
VEGETABLES			
Mushrooms	3 months	Leave button mushroom whole, slice larger ones. Trim stalks, wash, dry thoroughly. Freeze open (or sauted in a little butter till partially cooked then freeze).	Pack in boxes
Potatoes	3 months	New potatoes and chips can be frozen raw. Otherwise cook partially in one of usual forms, cool then freeze.	
Beans (Broad, French or Runner)	12 months	Peel or pod, and wash, top and tail. Cut large beans into shorter lengths or slice.	Blanch for 2 mins., cool for same time in iced water then freeze.
Carrots	12 months	Use small ones. Prepare by scraping, top and tail.	Blanch for 3-4 mins.
Cauliflower	12 months	Break up the florets and wash.	Blanch for 3 mins. Add lemon juice to water to improve whiteness.
Spinach	12 months	Wash thoroughly. Remove thicker veins. Chop if liked.	Blanch a few leave at a time, for 2 mins.
Sprouts	12 months	Use only small ones. Remove outer leaves.	Blanch for 3 mins – medium 1 1/2-2 mins – small.
Root crops	12 months	The younger the better. peel and slice or freeze whole.	Blanch for 3-5 mins.

	Max. Storage Period	Method	Remarks
FRUIT			
Apples	9-12 months	Freeze either of two ways: as puree-strew with little water, beat to smooth pulp, sweeten to taste, blanch for two mins., drain and cool. Pack tightly in layers with a little dry sugar sprinkled between, if so desired; or soak in slightly salted water for ten minutes, dry and freeze.	Freeze in small quantities. Pack in plastic containers, leaving 1.5 cm (1/2 in.) headroom.
Apricots	10-12 months	Preferably remove stones, but leave skins on. Pack in syrup 1/2-1lb. 200-400g (1/2-1lb) sugar to 550ml (1 pint) of water, making sure fruit is covered.	Pack in plastic containers, leaving 1.25-2.5 cm (1/2-1in.) 2.5cm (1/2-1in) headroom.
Cherries	12 months	ditto	ditto
Damsons	12 months	ditto	ditto
Plums	9 months	ditto	ditto
Gooseberries	12 months	ditto	ditto
Blackberries	12 months	Either pack in syrup as above, or coat with caster sugar and pack in plastic containers. Also may be frozen open then pack in containers.	ditto
Currants	12 months	ditto	ditto
Raspberries	12 months	ditto	ditto
Strawberries	12 months	ditto	ditto
Peaches	10 months	Cover with boiling water for 1 minute, then cool by dipping into cold and peel carefully. Cut into halves, removing stone. Use syrup method of packing and freezing.	Keep fruit submerged in syrup, place crumpled greaseproof paper on top, so there is no room between the surface of the liquid and the lid.
DAIRY PRODUCTS			
Eggs Whole	6 months	Pack leaving headspace, beat slightly.	do not freeze eggs in their shells as they will crack.
Egg Whites	6 months	Beat slightly, place whites in small containers just a few at a time.	
Egg Yolks	6 months	As for whites, but to prevent coagulation mix with 1/4 tsp. salt or 1/2 tsp. caster sugar to every two yolks.	Use for savoury or sweet dishes, label so that correct yolks are used.
Butter	6 months (unsalted) 3 months (salted)	Wrap bought butter in foil and freeze.	
Cream Whipping and Double only	3 months	Must first be beaten lightly before freezing. Rosettes of whipped cream can be piped onto silicone paper and open frozen.	Allow slight room for expansion in the container. Pack in layers.
Cheese	4 months (soft) 3-4 months (hard)	Wrap all varieties tightly in foil.	Hard cheese stores much better when grated.
BAKED ITEMS Wrap in foil or polythene bags			
Bread (Freshly baked)	1-2 months	Wrap and freeze	
Cakes, plain	6 months	Wrap and freeze	
Cakes, iced	3 months	Freeze without wrapping, then wrap and store in polythene.	
PREPARED FOODS			
Stews	2 months	May be frozen quite satisfactorily in a polythene bag.	Place bag inside a square plastic or cardboard box to shape the contents into bricks which save space in the freezer.
Sauces	4 months	Freeze in quantities of 275ml (1/2 pint)	Egg based sauces are unsuitable.
Full courses	3 months	Assemble individual helpings on specially constructed aluminium trays, then cover with foil. To re-heat leave the cover on and put in the oven for about 45 minutes at 200°C/Mark 6.	Cover slices of meat with gravy to prevent drying out.

CARING FOR YOUR FRIDGE/FREEZER

REPLACING THE LIGHT BULB

Should the interior light fail to work, first switch off and pull out the mains plug, and then replace the bulb as follows: (see fig. 15).



Remove the light cover by removing the screw at the rear with a screwdriver and pulling the cover outwards towards the middle of the cabinet. Unscrew the bulb and replace it with a new 15 watt E14 SES bulb (available from your local Electrolux Service Centre as listed on page 17).

To replace the light cover slide it into its original position and replace screw.

CLEANING AND CARE

SWITCH OFF THE APPLIANCE AT THE MAINS.

The interior of your appliance should be cleaned at regular intervals depending on usage. Always clean when food is at a minimum.

Empty the compartment and keep foods in a cool place.

Wash the interior and all fittings with a clean cloth wrung out in a bicarbonate of soda solution – 5 ml (1 teaspoon) bicarbonate of soda 500 ml (1 pint) warm water.

NEVER USE DETERGENTS OR ABRASIVE POWDERS TO CLEAN THE INTERIOR AS THESE WILL DAMAGE THE SURFACE AND LEAVE A STRONG SMELL.

The door seal should be cleaned with soapy water and thoroughly dried.

The outside should be wiped clean with a damp cloth and stubborn marks may be removed with a non-scratch cream cleanser. Wipe dry with a soft cloth. A small amount of wax spray polish may be applied to the exterior every few months to maintain the gloss finish.

The condenser grill situated at the back of the appliance should be dusted carefully occasionally.

Switch on at the mains and replace fittings and food.

IF GOING ON HOLIDAY

Don't switch off at the mains if you intend to leave food in the freezer.

If you are leaving the freezer empty, switch off at the wall socket and remove the plug. Defrost, clean and dry, and leave the door open.

SOMETHING NOT WORKING

SERVICE CHECK

Before calling your nearest Electrolux Service Centre. Carry out these simple checks.

If the appliance is noisy:

See "Normal Sounds" page 6.

1. If the appliance fails to operate:

- Is there a power failure? Check your house lights. If so, keep the door closed until the power is restored.
- Is the plug firmly connected to the wall socket and is the socket switched on? Check the power supply by plugging in another appliance or a table lamp.
- Is the fuse in the plug intact and are the wires in the mains lead correctly connected to the plug? (see page 5).

2. Have you turned the thermostat to the correct settings?

3. Has the door been left open causing the temperature to rise?

4. Sometimes the freezer door will be difficult to open shortly after you have closed it. Don't worry; this is due to a pressure difference which will quickly equalise and allow the door to open normally.


If, after following all these instructions, you are still having problems, contact your nearest Electrolux Service Centre. The telephone number is shown on the following pages.

RATING PLATE

The rating plate (A) is situated inside the cabinet behind the salad drawer or freezer bin (see fig 16). It gives the model and serial numbers which should be quoted in any communication. For future reference record the information below:

Model No:	
Serial No:	
Date of Purchase:	

Fig. 16



N.B. This appliance complies with the Radio Interference requirements of EEC Directive 82/499/EEC.

HELP US TO HELP YOU

SERVICE

Before calling out an engineer, please ensure you have followed the checklist.

Telephone numbers are detailed on the list headed "Electrolux Service Centres".

When you contact us we need to know:

1. Your name, address and post code.
2. Your telephone number.
3. Clear and concise details of the fault.
4. The model number.
5. When it was purchased.

Please note that all enquiries concerning service should be addressed to your local service centre.

Keep the receipt with this booklet as proof of purchase.

CUSTOMER CARE

For general enquiries concerning your Electrolux appliance, or further information on Cookers, Microwaves, Refrigeration or Home Laundry equipment you are invited to contact our Customer Care Department by letter or telephone as follows:

Customer Care,
Electrolux,
101 Oakley Road,
Luton,
Beds,
LU4 9QQ.

Tel: 0582 585858

ELECTROLUX SERVICE CENTRES

Service Centre	Postcode areas covered	Telephone	Address
ABERDEEN	DD IV KW AB PH	0224 696569	8 Cornhill Arcade, Cornhill Drive, Aberdeen AB2 5UT
ALTHAM-Manchester	SK M BL OL BB	0282 74621/2/3/4	PO Box 19, Altham Lane, Altham, Accrington, Lancs., BB5 5XY
BELFAST	BT	0232 746591	Unit C3, Edenderry Industrial Estate, 326 Crumlin Road, Belfast BT14 7EE
BIRMINGHAM	WR DY B WV TF ST SY WS	021 358 7076	8 Lammermoor Ave, Great Barr, Birmingham B43 6ET
BRIGHTON	BN RH	0273 694341	31 Bristol Gardens, Kemptown, Brighton BN2 5JR
BRISTOL	BA BS SN TA TQ EX TR PL	0272 211876 0626 65909	3 Waring House, Redcliffe Hill, Bristol BS1 6TB
CANVEY ISLAND	RM CM SS CO IG	0268 694144	2-4 Sandhurst, Kings Road, Canvey Island SS8 0QY
CARDIFF	CF HR LD NP SA	0222 460131	Guardian Industrial Estate, Clydesmuir Road, Tremorra, Cardiff CF2 2QS
GATESHEAD	CA DL DH NE SR TS	091 493 2025	Suite 3, Saltwell House, Lobley Hill Road, Gateshead NE8 4DD
GLASGOW	DG KA ML G PA	041 647 4381	20 Cunningham Road, Clyde Estate, Rutherglen, Glasgow G73 1PP
LEEDS	S DN HU YO WF HX HD, LS, HG, BD	0532 608511	64-66 Cross Gates Road, Leeds LS15 7NN
LEICESTER	LE DE CV NG LN PE IP NR	0533 515131 0603 667017	10-12 Buckminster Road, Leicester LE3 9AR
LIVERPOOL	CW CH LL L WA WN PR, FY, LA	051 254 1724	Unit 1, Honeys Green Lane, West Derby, Liverpool L12 9JR
LONDON (NORTH)	E EC WC N NW W EN	081 443 3464	Enfield Centre, 2-4 Sandhurst, Kings Road, Canvey Island SS8 0QY.
LONDON (SOUTH)	SE SM CR BR SW1 SW20	081 658 9069	127 Croydon Road, Beckenham, Kent BR3 3RA
LONDON (WEST)	AL CB LU MK SG WD HA, UB, TW	081 965 9699	842 Coronation Road, Park Royal, London NW10 7QA
OXFORD	GL HP NN OX SL RG	0993 704411	Suite 3, Windrush Court, 56a, High Street, Witney OX8 6BL
PORTSMOUTH	BH DT PO SO SP KT GU	0705 667411	Limberline Road, Hilsea, Portsmouth PO3 5JJ
TONBRIDGE	CT DA ME TN	0732 357722	61-63 High Street, Tonbridge TN9 1SD

GUARANTEE

This guarantee is offered to you as an extra benefit and does not affect your legal rights.

Electrolux products are carefully designed, manufactured, tested and inspected and in consequence we undertake to replace or repair any part found to be defective in material or workmanship, within one year of delivery to the original purchaser, free of charge.

The Company does not accept liability for defects arising from neglect, misuse, or accident.

There are certain conditions which may invalidate this guarantee:

- a) It is dependent upon the appliance being correctly installed and used in accordance with the Company's instructions under normal domestic conditions within the United Kingdom or the Republic of Ireland.
- b) Service at all times must be carried out by an Electrolux Service Representative or authorised agent.
- c) This guarantee may be invalidated by unauthorised repair or modification of the appliance.

Proof of the date of purchase will be required before service under guarantee is provided.

Addresses or telephone numbers for service requests as listed on page 17.

We must point out that this guarantee does not cover liability for loss of food or other contents, but would draw your attention to the insurance facilities described on the separate leaflet.

The Electrolux logo, featuring a stylized square icon with a circle inside, followed by the word "Electrolux" in a bold, serif typeface.

ELECTROLUX LTD., LUTON, BEDS., LU4 9QQ

In accordance with its policy of progressive product design
the Company reserves the right to alter specifications